



Setting Timed Dosing

- Always draw a picture of your dose tank when setting floats.
- Set your redundant off float 2 inches above the top of your pump.
- Set your timer 'off' float, 2 inches above the redundant off.
- Set your timer 'on' float, 6 inches above the timer 'on' – this gives you a minimum 4" tether.
- Your tether will be attached halfway between timer 'on' and timer 'off'.
- Measure how many inches of volume you will need in your tank between the timer 'off' and the timer override 'on' which should achieve an equalization volume minimum of 2X average flow at maximum occupancy.
- Set your timer override 'off' at the upper level of your equalization volume.
- Set your timer override 'on' six inches above your timer override 'off' to achieve a minimum 4" tether.
- Your alarm float should be set 2" above your timer override 'on'.